

# RCC205

## WHEELCHAIR LOADING ARM



The foldable wheelchair will be hanged up by this device and loaded inside the driver's cabin, in the rear side. It can be set up in almost all 5-doors cars where a sliding door is provided or fitted. The process starts by opening the sliding door using a button on the electric handset, then the wheelchair loading arm is driven out by another button on the same handset, after the door has reached its maximum opening. When the loading arm has reached its maximum position outside the vehicle, the wheelchair can be fastened onto the hooks of the arm and, by pressing another button, lifted up inside the vehicle, with an inclination of 45°. If the device is not used in the car, it can be easily removed. The original rear seats can be easily re-introduced. If needed, the wheelchair loading arm can be manually operated.



ELECTROMAGNETIC  
COMPATIBILITY  
TESTED



[www.kivi.it](http://www.kivi.it) | [info@kivi.it](mailto:info@kivi.it)

 [facebook.com/Kivi.Fan.page](https://facebook.com/Kivi.Fan.page)

 [youtube.com/KiviMobilityFreedom](https://youtube.com/KiviMobilityFreedom)

DEALER